

Display




Watch mode Time zone correction A Setting crown in position 2

Watch mode Adjusting hour, date and month




Note: Do not try adjusting the date and month in timing mode, as the buttons will not work.

Tachometer



Example: 1 km covered in 25 sec. means a speed of 144 km/h


Turning bezel



Watch

Watch mod

Timing mode Simple chronograph function




Warning: Before each timing, the hands must be at zero. If necessary, press button B. Note: The contents of the memory may be read either before or after zero reset.

1) to (8) order of operations

Add or rally function

Timing mo




1) START 1

2 STOP 1

STOP 1 time is memorized

At next START, 1/100 sec.hand returns to zero but catches up the 1/100 memorized at STOP



3 START 2

4 STOP 2

STOP 2 time is memorized

- 1 hour - 44 minutes - 25 seconds - 63/100 sec.

Read time 2


(6) Zero reset


Note: After the 11th STOP, the time flashes in the left-hand window. The memory capacity is exceeded; only the first ten times and the total time will be recorded the memory.

① to ⑥ order of operation

Timing mode

Add or rally function: reading times memorized





End of memory reading

1st pressure = reset to zero
2nd pressure =

delete memory

Note: Contents of memory may be read either before or after zero reset.

1) to 3) order of operations

Split or intermediate times function

Timing m


(1) START Read time 1 -1 hour - 20 minutes 3 - 26 seconds M -55/100 sec.

Note: After pressing push-button B once and the time delay for reading, the hands catch up the time measured, the 1/100 of a second hand returns to zero but catches up the 1/100 memorized during the next SPLIT. ① to ③ order of operation

(2) SPLIT 1

Timing mode


Split or intermediate times function



Note: From SPLIT 11, the number of the times flashes (left-hand window). The capacity of the memory is exceeded, and only the STOP time will be recorded in the memory.

(4) to (8) order of operatings (continued)

Split or intermediate times function: how to read times memorized Timing mo




Note: Subsequent pressures of button M display the memorized SPLIT times one after the other, as well as the STOP time.

The contents of the memory may be read either before or after reset to zero.


1) to 3 order of operations

Timing mode

LAP-time function




1) to 3) order of operations




Note: After pressing button C and the read-out time delay, the hands catch up the time measured since the previous LAP, and the 1/100 of a second hand returns to zero. After LAP 11, the number of the time flashes. All subsequent times are added to the first 10 and the total is placed in the memory and designated by the letter T.

(continued)



LAP-time function: how to read times memorized Timing mode



Note: Subsequent pressures of M display LAP-time 2, LAP-time 3 and then T again and so on. The contents of the memory can be read before or after return to zero.


1) to (5) order of operations

Setting the hands of the chronograph

Watch mode

ACCUPATION OF THE PROPERTY OF THE PARTY OF

- 1. Put the winding-crown in position 2.
- 2. By means of short, successive pressures on the push-piece, turn the hand "step by step" back to zero. Repeat the operation for each of the push-pieces (to make the hand move rapidly, apply continuous pressure).
 - Push-piece A: works the hours counter
 - Push-piece B: works the minutes counter
 - Push-piece C: works the seconds hand
 - Push-piece M: works the 100th-second hand
- 3. The winding-crown can be used to correct the position of the hours hand (when changing time zones) and the date, without disturbing the seconds.
- 4. Push the winding-stem in and tighten the crown.




After a battery change or if the function should be affected by a severe knock or exposure to a strong magnetic field, the hands of the chronograph should be reset at zero (starting point).

Note: Do not keep the setting crown in position 2 for more than 20 minutes (loss of hour).

Starting memories (Resetting memories to zero)

Watch mot






Automatic: at each START following the zero reset

Manual: by pressing B after reset to zero

Correction of time delay for Watch mode reading intermediate times



Note: Do not try correcting time delay in timing mode because the buttons will not work.